


PANZITTA SALES & SERVICE
 72 George Avenue
 Wilkes-Barre, PA 18705
 570-822-6720 800-822-6720
 www.panzittasales.com



20-20 AIR-FLATE




This Parts List is for
units with

Serial No. 20-20A-54,994 and up
Manufactured by The Coats Company:

1601 J. P. Hennessy Drive
 La Vergne, TN. 37086
 PHONE: 615-793-7533
 TWX: 810-380-4372

ORDER PARTS FROM YOUR DISTRIBUTOR OR JOBBER

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
1	000433	Hold Down Cone	73	102937	3/4" Lock Nut N.F. (Ea.)	140	103733	Hose (9")
2	104250	Center Shaft Assembly	74	104120	Support Bracket	141	104137	Air Gauge Mtg. Bracket (Ea.)
3	000304	1/4 x 1 1/4 Nylon Bearing	75	103260	1/2" Lock Nut N.F. (Ea.)	142	103736	Air Gauge
4	104253	Machine Bushing	76	104354	Stud Kit	143	105366	Lens Assy.
5	000510	1 1/4 x 1 1/4 Nylon Bearing	77	103006	5/32 x 1 1/2 Cotter Pin	144	104755	Tinnerman Nut
7	101296	1/4" Drive Gear Bolt (Ea.)	78	104115	Detent Arm	145	104945	1/4" x 3/4" Self Tapping Bolt (Ea.)
8	100958	Self Aligning Washer	79	103814	3/4 x 1 1/2 Cap Screw N.F.	146	104564	Ring Fastener (Ea.)
10	101156	1 1/4" Self Aligning Bushing (Ea.)	80	104198	3/4 x 6" Cap Screw N.F.	147	105671	End Cap (1/4" Valve)
11	100960	Self Aligning Bushing (Ea.)	81	104108	Foot Valve Plate	148	106278	Male Branch Tee
12	101253	3/4" Machine Bushing (Ea.)	84	104355	Valve Cap (Ea.)	149	104649	Poppet (1/4 Valve)
13	100957	3/4" Lock Nut (Ea.)	85	104266	Valve Complete	150	104600	1/4" Valve Comp.
14	100964	1 1/4 Snap Ring (Ea.)	86	104209	Muffler	151	104673	Bushing 1/4" Valve
15	101298	Gear Tie Bar	87	102468	Poppet Spring (Ea.)	152	104613	3/8" External Lock Washer
16	101352	Tie Bar Nylon Bearing	88	102469	Poppet (Ea.)	153	104611	3/8" Jam Nut N.F.
17	101089	Drive Gear Bar Assembly	89	104147	3/4" x 5" Cap Screw N.F.	154	106350	End Cap (3/4" Valve)
18	104247	Drive Gear Complete	90	103815	3/4" x 1" Cap Screw N.F.	155	106350	Spring (3/4" Valve)
19	100951	Pinion	91	104110	Valve Bracket	156	104652	Poppet (3/4" Valve)
20	101091	Shaft Key	92	104149	Valve Spring (Ea.)	157	104629	3/4" Valve Complete
22	104246	Center Post Adapter	93	104154	3/4" x 4 1/2" Clevis Pin (Ea.)	158	104674	Bushing 3/4" Valve
23	104245	Center Post Extension	94	104173	Shoulder Bolt (Ea.)	159	104612	3/4" External Lock Washer
24	101042	Large Lower Shoe	95	000628	5/16" Lock Nut N.F. (Ea.)	160	104610	3/4" Jam Nut N.F.
25	101251	Small Lower Shoe	96	104676	Top Cover	161	105520	Foot Panel
26	100994	Shoe Spacer (Ea.)	97	105670	Side Panel R.H.	166	103648	Hose 36"
27	102927	1/4" Shim	98	104944	Front Panel	167	104596	10-32 Self Tapping Screw
28	101003	Lower Shoe Shaft	99	104949	Parts Tray	168	104844	1/4" Straight Fitting
29	101001	3/4" Snap Ring (Ea.)	100	106035	Foot Pedal	169	106283	Hose (24 1/4")
30	105133	Shoe Adjusting Bar	101	106190	Foot Pedal Kit	170	106237	Air Tube
31	101506	Shoe Adjusting Shim Kit	102	105669	Side Panel L.H.	174	103264	3/4" x 1 1/4" Machine Bushing
32	105131	3/4 x 1 1/4 Self Tapping Screw	103	101110	3/4" Self Tapping Screw (Ea.)	175	101427	Hose Clamp
33	104012	Return Spring (Ea.)	104	104298	Plastic Plug (Ea.)	176	108016	Warning Decal
34	101002	Upper Cylinder Shaft	105	102459	3/4" Self Tapping Bolt (Ea.)	177	105824	Cap Plug
35	104235	Power Arm	106	000528	3/4" x 1 Tinnerman Nut (Ea.)	178	106188	Strainer Screen
36	101039	1/2" Lock Nut N.C. (Ea.)	107	000529	Tinnerman Nut (Ea.)	179	107142	Clip Spring Kit
38	101040	1/2 x 3/4 Cap Screw (N.C.)	108	104101	Short Leg	180	108059	Inflation Warning Decal
39	101351	Nylon Bearing (Ea.)	109	103151	Spacer (Ea.)			
40	101651	Machine Bushing (Ea.)	110	104682	Console			
41	101411	1 Qt Special Hydraulic Oil (Ea.)	112	102048	Hose (15")			
42	105678	Plastic Breather Plug	113	104102	Rear Panel			
44	000580	Close Nipple	114	106259	Lube Bottle			
45	107242	7" Cylinder	115	000598	7/16" x 3/4" Cap Screw N.C.			
46	000372	1/4" x 90' Street Elbow	116	000490	Lube Bracket			
47	101898	3/4" Hose Fitting (Ea.)	117	000755	7/16" Square Nut			
49	102785	Hose (28")	118	000534	7/16" Lock Washer			
50	101000	Lower Cylinder Shaft	119	000491	Lube Applicator			
51	104156	Chassis	120	000768	Combination Tool			
52	105810	1/4" x 2" Cotter Pin	121	104900	Surge Tank			
53	100970	Power Arm Axle	122	000572	3/4" x 90' Street Ell.			
54	104026	Extension Tube	123	104573	3/4" Straight Fitting (Ea.)			
55	104267	Clevis Pin	124	101346	Hose Clamp (Ea.)			
56	104024	Adjustable Upper Bead Loosener Arm	125	104679	Hose (29 1/2")			
57	102376	1/2 x 3/4" Cap Screw N.C.	126	101312	Reducing Bushing (3/4"-1/4")			
58	100979	Top Bead Breaker Handle Grip (Ea.)	127	106284	Hose (13 1/4")			
59	102276	Clevis Pin	128	000643	1/4" Tee (Ea.)			
60	010027	1/2" Washer (Ea.)	129	000378	Hose Fitting			
61	102278	1/4 x 1 Cotter Pin (Ea.)	130	102390	1/4" Hose Fitting (Ea.)			
62	101106	Top Bead Shoe Breaker Spring	131	104583	Hose (48")			
63	100988	Top Bead Loosener Shoe Comp.	132	103861	1/4" Hose Fitting (Ea.)			
64	101163	Top Bead Breaker Nose	133	104968	Safety Valve			
65	103671	Positioning Pin Spring	134	104681	4-Way Fitting			
66	103670	Positioning Pin	135	103737	Release Valve			
67	104319	Positioning Pin Extension	136	000745	1/4" Flat Washer (Ea.)			
68	104155	Knob	137	101428	Hose Clamp			
70	104262	Push Handle	138	103753	Air Chuck			
71	104284	Detent Spring	139	104138	Air Gauge Mtg. Nut (Ea.)			





20·20 AIR-FLATE PARTS LIST

