


MODEL SPO94
PARTS BREAKDOWN



REPLACEMENT PARTS					
ITEM NO.	DESCRIPTION	PART NO.	ITEM NO.	DESCRIPTION	PART NO.
1	R.H. Column	FJ7293	26	Foam Tape	FJ761-4
2	L.H. Column	FJ7292	27	Slider Block	FJ7236
3	Cable Housing	FJ7163-1	28	Arm Pin	FJ730-4
4	Column Extension	FJ7164	29	1/4"-20NC x 3/4" Lg.	4 REQ'D
5	Power Unit	P502	30	1/4"-20NC Hex Nut, 1/4" LW	4 EA. REQ'D
6	R.H. Swinging Arm	FJ7229	31	3/8"-16NC HHCS x 1 1/4" Lg.	4 REQ'D
7	L.H. Swinging Arm	FJ7230	32	3/8" Hex Nut, 3/8" Ext. Tooth LW	4 EA. REQ'D
8	Hydraulic Cylinder	FJ7211	33	3/8"-16NC HHCS x 3/4" Lg.	16 REQ'D
9	Carriage Yoke	FJ7265-1	34	3/8"-16NC Hex Nut, 3/8" Ext. Tooth LW	16 REQ'D
10	Switch Bar	FJ7108-7-1-1	35	Bleeder Screw (MF)	2 REQ'D
10a	Long Cushion	FJ7165	36	Cylinder Adapter	FJ741-7
11	Equalizer Cable	FJ7165	37	1/2"-13NC x 3/4" Lg. HHCS	8 REQ'D
12	Optional Rubber Pad Adapter	FJ697	38	3/4" Anchor Bolt (16 Req'd)	FJ7380
13	Overhead Hose	FJ86	39	1/4"-20NC x 2" Lg. HS HHCS	2 REQ'D
14	Locking Latch Kit	FJ748	40	1/2"-13NC Hex Nut, 1/2"-13NC Hex Jam Nut	4 EA. REQ'D
15	Sheave	FJ7116-1	41	1/8" x 1" Lg. Cotter Pin	FJ7108-7-4
16	Sheave Kit	FJ7160	42	5/16"-18NC HHCS x 3/4" Lg.	4 REQ'D
17	Wheel Spotting Dish	FF729	43	5/16" Hex Nut	4 REQ'D
18	Power Unit Hose	FJ7191	44	3/4" Washer	FJ7108-7-3
19	Sliding Base	FJ7213-1	45	L.H. Outer Tube	FJ7233-7
20	Overhead Switch Assembly	FJ7108-2		R.H. Outer Tube	FJ7233-11
21	Safety Switch Bracket	FJ7198-7-2	46	Rod	FJ7233-27
22	High Step Adapter	FJ761-1	47	Plunger Ass'y	FJ7233-25
23	Low Step Adapter	FJ671-2	48	Ball Handle	FC134-9-10
24	Adapter Pin	FJ671-3	49	Spring	FC134-9-7
24a	Hog Ring For 1/2" Shaft	FJ671-6	50	Clevis Pin	FJ7233-22
25	Swivel Pin	FJ671-5	51	1/8" x 1" Cotter Pin	8 REQ'D

OWNERS RECORD

Complete information
at right and keep in
a safe place.

Date Installed _____
Installed in Bay # _____
Std. Serial # _____ P502
3 ph. Serial # _____ P504
Factory Order # L _____

IMPORTANT: When ordering parts
always give exact model and power
unit serial number. Model number is
shown on nameplate attached to
base angle. Serial number is located
on side of power unit reservoir.

NOTE: For Replacement Parts -

PANZITTA SALES & SERVICE

72 George Avenue

Wilkes-Barre, PA 18705

570-822-6720 800-822-6720

www.panzittasales.com

INDEX 2.2.2

Revised 10-88

